




PlayStation One Lens Replacement

This will guide you in replacing of your PlayStation Lense

Written By: trickster



Step 1 — Upper Case



- Remove all cables plugged into the PlayStation.

Step 2



- Flip over the PlayStation and remove the six screws from the bottom.


Step 3



- Flip the PlayStation back.



⚠ There are no screws holding EVERYTHING inside the PlayStation so better hold it like a burger while flipping.

Step 4



- Lift up and remove the upper case.

Step 5 — Lens



- Disconnect the ribbon cable and wired cable connectors.
- Take extreme care when disconnecting ribbon cable from motherboard. Tears extremely easy.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 05:40:12 PM.